


TileBud Kit Contents Include:



SEALUX30 Strip




Strip Alignment Card (Box Flap)





Alcohol Wipes



Sealant Smoothing Spatula



Installation Instructions



Drawings are not to scale

(1) Mark strip start and end points on wall 10mm outside proposed receptor (bathtub/shower base) ends (Fig. 3). To define position of strip upper edge line on wall, apply wall marks $X+75\text{mm}$ above floor, where X will be receptor ledge height above floor after installation (Figs. 1 & 3). Alternatively, the strip upper edge line position on wall can be defined by installing receptor temporarily in its final position, resting the folded strip alignment card on ledge and marking walls 75mm above ledge (Fig. 1b). Draw wall lines through wall marks. (2) Measure and cut strip to length. (3) Referring to Fig. 2 below, using painter's tape tabs, align and hang strip in position on wall ensuring strip extends fully into wall corner(s). Progressively pulling blue release liner downward off back of strip, press-bond exposed adhesive bed to wall without creasing strip in the process. Remove painter's tape tabs when done. (4) Fold strip upper portion back off wall and using an approved polymer adhesive, tile adhesive or

waterproofing compound, bond strip upper portion permanently to wall (Fig. 3), using the spatula to press strip firmly against wall and push strip fully into wall corner(s). If bonding strip to wall with silicone sealant, apply painter's tape on wall just outside strip upper and end boundaries to ensure sealant does not smear the wall face. Do not smear silicone over fleece face of strip. (5) Clean receptor ledge and sidewalls intended to face wall mounted strip with alcohol wipes. Apply painter's tape just outside ledge corner(s) to prevent smearing silicone on ledge during installation (Fig. 4). (6) Install receptor keeping a 6mm gap between receptor sidewalls and adjacent strip bonded to wall. Ensure receptor rests steady on floor. Check receptor waste outlet and pipe joints for leaks. (7) Apply a neutral curing sanitary grade silicone into first side joint and rub up ensuring the exposed sealant upper face falls downward from wall to ledge. Ensure a minimum silicone engagement face of at least 6mm is made with both strip and receptor sidewall. Seal remaining joints in a similar fashion. Remove painter's tape off receptor ledge when finished.

